

SEM

MAGNETOS

Type EY-2R36

for Albin engines model O-21

DATA:

Cylinders: two

Rotation: clockwise

Timing range: 20°



Weight: 2.8 kgs

Drawing: No. 17204

SEM

SERVICE- LIST

ME — 242



DESCRIPTION

SEM Magnetos type EY-2R36 are of a design employing the rotating magnet principle. The permanent magnet of Alnico-steel is diecast in a single unit with the laminated pole pieces and the spindles to form the magneto rotor. The less robust parts, such as the coil and condenser, are stationary. The contact breaker, which does not rotate, is of the pivotal type and entirely enclosed in a metal casing. The magnetos are designed for service under the most arduous conditions. The entire units are enclosed within a dust- and moisture-proof metal frame. The coil is effectively insulated by a method which protects against deterioration and power leakage under adverse running conditions.

INSPECTION AND MAINTENANCE

When faulty ignition occurs, the high tension cables and sparking plugs should first be examined. If the insulation shows signs of deterioration or cracking, the cables must be exchanged. For this purpose the main cover of the magneto housing need not be removed. Unscrew the nut on the cable outlet and remove the cable. The new cable should not be bared but must be cut off flush to the required length. The rubber is pulled onto the cable for a distance of at least 40 mm from its end and the cable is pushed well down into the bottom of the insulator. The nut on the cable outlet must then be screwed home.

The plug electrodes burn away slightly in service whereby the gap length gradually increases. Examine and clean them from time to time, adjusting them if necessary. For the right distance follow the instructions of the engine manufacturer.

ADJUSTMENT OF BREAKER POINTS

The contact breaker should be inspected from time to time. It is important that the contacts should be kept clean. If they are burned or blackened, they may be cleaned with a very fine car-

borundum stone or emery cloth. Care must be taken that all particles of dirt or metal dust are wiped away. This can be done with a cloth moistened with petrol.

The gap between the contacts, when fully opened, should be 0,4 mm. The distance can be checked by means of the gauge on the adjusting spanner. If adjustment is necessary, proceed as follows. Slack off the screw A (See fig.) slightly. Insert the screw driver of the adjusting spanner in the slot C. Turning the spanner to the left decreases, and turning to the right increases, the distance between the contacts. When the gap is set to the thickness of the gauge tighten the screw A.

If the cam is removed from the shaft for any reason, make sure that it is replaced in its original position. The end surfaces of the cam are marked with an R and an L respectively. On magnetos for a right-hand drive the letter R must be turned towards the breaker cover. On magnetos for a left-hand drive the letter L should have the same position.

If the moving contact D is to be replaced, unscrew the nut F with the adjusting spanner and remove the split pin G. Fill the groove of the contact breaker pivot with ball bearing grease and install the new moving contact. If the felt lubricator H is dry, add a few drops of thin machine oil onto the felt. When replacing the contact breaker housing, fill its lubricating groove with ball bearing grease before assembly.

REPLACEMENT OF CONDENSER

When replacing the condenser remove the two retaining screws. When reassembling ensure that the cable connections from the contact breaker and the wound core are replaced in their original positions. The eyelet from the winding and the nickel-plated cable terminal from the contact breaker are placed under one of the retaining screws. The brass cable terminal from the contact breaker and the eyelets from the ignition coil and condenser are placed under the retaining screw for the shorting spring clip.

CLEANING OF HIGH TENSION MOULDING AND SLIP RING

The high tension moulding should be removed about once a year and cleaned. Wipe off any deposits and polish with a fine dry cloth. See that the pick up brushes move freely in their holders. Before replacing the high tension moulding, clean the slip ring by inserting a soft cloth and at the same time slowly turning the engine. When reassembling ensure that the cable connections from the wound core, the condenser and the contact breaker are made according to the instructions for replacement of the condenser.

AKTIEBOLAGET SVENSKA ELEKTROMAGNETER - ÅMÅL - SWEDEN


TELEPHONE: 120 10

Telegraphic address: MAGNETER



MAGNETOS type EY-2R36

for Albin engines model O-21



SPARE PARTS LIST

Fig. No.		Order No.	Fig. No.		Order No.
1	Main housing	17305	26	Short circuiting spring clip	17270
2	Retaining spring	17030	—	Screw for short circuiting spring clip (CS 4×8) ..	2638
3	Rotor	17231	27	Collector carbon with spring	1954
4	Contact breaker cam	17239	28	Collector carbon (cylindrical) with spring	17268
—	Retaining screw with washers for contact breaker cam	17059	—	Retaining screw for high tension moulding (CS 4×18)	2720
—	Woodruff key for contact breaker cam	17051	—	Washer for screw 2720 (diam. 8 hole 4.1) ..	1766
5	Ball bearing, breaker end	1761	—	Spring washer for screw 2720 (FB 4.3) ..	2463
6	Ball bearing packing, breaker end	17052	29	Main housing cover	17279
—	Felt packing, breaker end (diam. 28 hole 11) ..	1704	30	Retaining screw for main housing cover ..	17148
—	Adjustment washers (assortment of 4) diam. 17.5 hole 12	1750	31	Insulating bush for high tension cable outlet ..	17145
—	Spring washer (diam. 26 hole 12.1)	17240	32	Rubber bush for cable outlet	14123
7	Slip ring	17236	33	Nut for cable outlet	17146
—	Ball bearing, drive shaft end	1760	34	Flat terminal	1819
—	Ball bearing packing, drive shaft end	17039	35	Contact screw for shorting cable	17147
8	Rubber packing, drive shaft end	17038	—	Metal washer for same	17152
9	Woodruff key, drive shaft end	1597	—	Insulating washer for same (diam. 15 hole 7) ..	17151
10	Bearing plate	17061	—	Nut for same	17157
11	Contact breaker housing complete	17245	36	Short circuiting push button, complete ..	17156
12	Contact breaker housing	17064	37	Spanner	1649
13	Contact plate with contact	17069		IMPULSE STARTER	
—	Retaining screw for contact plate (PKCS 3.5×4.5)	17093	50	Casing	17365
—	Washer for contact plate (diam. 7 hole 3.5) ..	10159	—	Retaining screw for casing (7/32"×24) ..	17360
14	Contact breaker lever	17071	51	Fixed stop	17306
—	Washer for contact breaker pivot (diam. 8 hole 4.6)	17131	—	Retaining screw for same (7/32"×10) ..	3023
15	Lock spring for contact breaker pivot ..	17063	52	Pawl disc	17307
16	Screw for cable connection with bush, insulating washers and nuts	17097	53	Pawl	17313
—	Nut only for cable connection	17094	—	Washer for pawl (diam. 8 hole 5) ..	1736
17	Earthing cable with felt lubricator	17246	—	Lock spring for pawl pivot	17354
18	Contact breaker cable connection	17080	54	Washer for pawl disc	17345
19	Stop screw for contact breaker housing ..	17081	55	Lock nut for pawl disc	17341
20	Contact breaker cover	17082	56	Spring housing	17391
21	Timing lever	17088	57	Impulse spring	17325
—	Retaining screw for bearing plate	17086	58	Adjustment washers (assortment of 5) ..	17352
22	Breaker cover spring and stud	17083	—	Ball bearing	1760
23	Wound core	17250	—	Ball bearing packing	17039
24	Condenser	17272	59	Oil seal	17389
25	High tension moulding	17256	60	Woodruff key for drive shaft	1597
			—	Spring washer for drive shaft (FB 9.5) ..	10203
			—	Nut for drive shaft (LB6M-9)	10110

When ordering spare parts please state, in addition to the order number of the part (not number of the Fig.) also the type and factory number of the magneto.

AKTIEBOLAGET SVENSKA ELEKTROMAGNETER - ÅMÅL

TELEPHONE: 120 10

SWEDEN

Telegraphic address: MAGNETER

